


LANDA®


TRAILER OPERATOR'S MANUAL

■ TR-3500

■ TR-6000



89139560-5



89139560-11

Shown with optional equipment

For technical assistance or the Landa Dealer nearest you, consult our web page at www.landa.com

8.913-956.0

CONTENTS

| | |
|--|-------|
| Introduction..... | 4 |
| Machine Safety..... | 4 |
| Reporting Safety Defects..... | 4 |
| Checklist, Before Your First Trip | 4 |
| What to Check & How to Check | 4-6 |
| Brakes | 7 |
| Trailer Storage | 7 |
| Exploded View, TR3500..... | 8 |
| Exploded View, Parts List, TR3500..... | 9 |
| Exploded View, TR3500/PGHW | 10 |
| Exploded View, Parts List, TR3500/PGHW | 11 |
| Exploded View, TR-6000 | 12-13 |
| Exploded View, Parts List, TR-6000 | 14-15 |
| Exploded View, TR-6000/PGHW | 16-17 |
| Exploded View, TR-6000/PGHW Parts List | 18 |
| Wiring Diagram..... | 19 |
| Preventative Maintenance | 20 |
| Trailer Options & Accessories..... | 21-22 |
| Warranty | 23 |

INTRODUCTION

Thank you for purchasing a Landa trailer.

This manual is designed to provide information to help you to understand, use and maintain Landa trailers TR-3500 and TR-6000.

Owner/User Responsibility


The owner and/or user must have an understanding of the manufacturer's operating instructions and warnings before using this equipment. Warning information should be emphasized and understood. If the operator is not fluent in English, the manufacturer's instructions and warning shall be read to and discussed with the operator in the operator's native language by the purchaser/owner, making sure that the operator comprehends its contents.

Owner and/or user must study and maintain for future reference the manufacturer's instructions.

This manual should be considered a permanent part of the equipment and should remain with it if unit is resold.

When ordering parts, please specify model and serial number.

MACHINE SAFETY



WARNING: To reduce the risk of injury, read operating instructions carefully before using.

1. Read the owner's manual thoroughly. Failure to follow instructions could cause malfunction of the unit and result in death, serious bodily injury and/or property damage.
2. The best insurance against an accident is precaution and knowledge of this equipment.

REPORTING SAFETY DEFECTS

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Landa.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer or Landa.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 366-0123 in Washington, DC area) or write to NHTSA, U.S. Department of Transportation, Washington, DC 20590. You can also obtain other information about motor vehicle safety from the Hotline.

CHECKLIST

Before Your First Trip

- ☐ Tire Pressure and Tire Condition
- ☐ Wheel Lugs*
- ☐ Bearing Lube and Tightness
- ☐ Burnish Brakes (See page 6)
- ☐ Brakes/Brake Controllers
- ☐ Breakaway Battery Charge
- ☐ Hitch
- ☐ Safety Chains
- ☐ 12V Running Lights
- ☐ Distribution and Security
- ☐ All Jacks "Up" in Travel Position

* Check lug nuts for tightness before initial trip, at 10 miles, 25 miles and 50 miles. Recheck every 3 months or 3000 miles.

Your Landa Dealer, in all probability, checked each of these points before you took delivery. However, these are key things you should recheck before taking your trailer on the road for the first time.

WHAT TO CHECK AND HOW TO CHECK

Tire Pressure

Proper air pressure for your tires is printed on the sidewall. Check pressure while tires are cold. Do not raise or lower pressure to meet load. Pressure other than recommended pressure will lead to excessive tire wear or tire failure. Balancing recommended. Preferred balancing method is to center off of stud holes, since 13" through 16.5" wheels are not hub piloted.


Wheels

Check wheels for hole elongation or "out of round". This condition can be caused by lug nuts not being tight or being too tight. Trailer wheels can be damaged by chuck holes or curb jumping. You may not be aware of the road shock to the wheels without periodic checks. Replace any wheel that is bent. Replace any wheel if you see elongation of the bolt holes.

Wheel Lugs

Wheel lug nuts must be tightened with a torque wrench. Refer to the chart below for proper torque

1. Start all bolts or nuts by hand to prevent cross threading.
2. Tighten bolts or nuts following sequence at right.
3. The tightening of the fasteners should be done in stages. Following the recommended sequence, tighten fasteners per wheel torque chart below.
4. Wheel nuts/bolts should be torqued before first road use and after each wheel removal. Check and re-torque after the first 10 miles, 25 miles and again at 50 miles. Check periodically thereafter.



Wheel Torque Requirements

TORQUE SEQUENCE

| WHEEL SIZE | 1st Stage | 2nd Stage | 3rd Stage |
|------------|-----------|-----------|-----------|
| 14" | 20 - 25 | 50 - 60 | 90 - 120 |

Ball Coupler Hitches

Coupler assembly includes a latch lever and latch lever safety pin or hitch pin. Be sure the latch lever is locked and the pin properly secured before moving your trailer. The pin can be engaged fully only if ball is properly seated in the coupler.

Hitch Balls

These come in a variety of diameters and capacities. The GVWR (General Vehicle Weight Rating) capacity is always stamped on the ball. Use a 2" ball. **Always** be sure the hitch ball at least matches the GVWR of your trailer. **Always** be sure the diameter of the hitch ball matches the coupler diameter. **Never** attempt to tow your trailer with improper size ball. **Always** keep ball greased to avoid excessive wear. Replace worn hitch ball or locking dogs promptly.

Tires

Before mounting tires onto wheels make certain that the rim size and contour is approved for the tire as shown in the Tire and Rim Association Yearbook or the tire manufacturer's catalog. Also make sure the tire will carry the rated load. If the load is not equal on all tires due to trailer weight distribution, use the tire rated for the heaviest wheel position.







Note: The capacity rating molded into the sidewall of the tire is not always the proper rating for the tire if used in a trailer application. Use the following guideline:

1. LT and ST tires: use the capacity rating molded into the tire.
2. Passenger Car Tires: Use the capacity rating molded into the tire sidewall divided by 1.10.

Use tire mounting procedures as outlined by the Rubber Manufacturer's Association or the tire manufacturers.

Tire inflation pressure is the most important factor in tire life. Inflation pressure should be as recommended by the manufacturer for the load. Pressure should be checked cold before operation. Do not bleed air from tires when they are hot. Check inflation pressure weekly during use to insure the maximum tire life and tread wear. The following tire wear diagnostic chart will help you pinpoint the causes and solutions of tire wear problems.

Note: Tire wear should be checked frequently because once a wear pattern becomes firmly established in a tire it is difficult to stop, even if the underlying cause is corrected.

| WEAR PATTERN | CAUSE | ACTION |
|--|-------------------------------|---|
|  Center Wear | Over Inflation | Adjust pressure to particular load per tire catalog. |
|  Edge Wear | Under Inflation | Adjust pressure to particular load per tire catalog. |
|  Side Wear | Loss of camber or overloading | Make sure load doesn't exceed axle rating. Align at alignment shop. |
|  Toe Wear | Incorrect toe-in | Align at alignment shop. |
|  Cupping | Out of balance | Check bearing adjustment and balance tires. |
|  Flat Spots | Wheel lockup & tire skidding | Avoid sudden stops when possible and adjust brakes. |

Safety Chains

Your trailer is equipped with safety chains that meet the requirements of *D.O.T. Regulations 393.70*.

Always attach the chains by crossing them, forming a "cradle". If your coupler disengages for any reason, the "cradle" will keep the hitch from dragging on the ground. You'll be able to make an easier and safer stop.

Safety Chain Hook-Up

Abrasion (possibly from dragging on the ground) or unusual stress (like the situation described above) can weaken the links, making them unsafe for trailering. If you detect any of these conditions, *replace the safety chains!* If chains are too long, twist to shorten, and prevent dragging.

Brakes

Your trailer is equipped with one of several brake type options.

Complete service and repair information for each available type brake is found in the Dexter Service Manual that is furnished with your trailer.


Note: It is important to strictly adhere to the Dexter instructions for brake service and repair. In this way, you are protecting the validity of all applicable warranties.

Burnishing the Brakes

Brakes on a new trailer may tend to "grab" or pulsate. This is normal. To correct the situation, pull the trailer with the trailer brake control slightly engaged a short distance (about 1000 ft or until trailer does not grab or pull to one side anymore). This action smooths down the brake bands.

Note: Do not lock up the wheels.

Breakaway Battery on A-Frame



Breakaway Switch & D.O.T. Wet Cell Battery

After hitching to the tow vehicle, pull the safety pin on the breakaway switch. Check to see if system is operational. Push safety pin back in to its original position.

Check battery fluid level every 60-90 days. Remove cover. There are two fill caps. Refill with distilled water only.

Breakaway Switch Mounted on an A-Frame

Attach breakaway switch cable securely in a straight line to the tow vehicle. Locate attachments so little "slack" is left in the cable, but enough slack to allow for turning without disengaging the pin. The cable will activate brakes the instant a trailer becomes disengaged. Brake adjustment is critical to stopping a disengaged trailer.

Check Breakaway System & Brakes Before Each Trip

1. Disconnect 12V plug from tow vehicle.
2. Pull breakaway pin.
3. While pin is pulled, move tow vehicle forward. Brake should be on and wheels locked.
4. Replace pin and secure to tow vehicle. Do not loop over hitch ball.
5. Plug 12V connector into tow vehicle receptacle.
6. Test brakes with brake controller.

NOTE: When disconnecting trailer from tow vehicle, make sure to replace safety pin.

BRAKES

Brake Adjustment

Brakes should be adjusted (1) after the first 200 miles of operation after the brake shoes and drums have "seated", (2) at 3000 mile intervals and (3) as use and performance require. The brakes should be adjusted in the following manner:

1. Jack up trailer and secure on adequate capacity jack stands. Check that wheel and drum rotate freely.
2. Remove adjusting hole cover from adjusting slot on bottom of brake backing plate.
3. With screwdriver or standard adjusting tool, rotate the starwheel of the adjuster assembly to expand the brake shoes. Adjust the brake shoes out until the pressure of the linings against the drum makes the wheel very difficult to turn.

Note: With drop spindle axles, a modified adjusting tool with about an 80 degree angle should be used.

4. Then rotate starwheel in opposite direction until wheel turns freely with slight lining drag.
5. Replace the adjusting hole cover and lower wheel to ground.
6. Repeat above procedure on all brakes.



CAUTION: Never crawl under your trailer unless it is resting on properly placed jack stands.

Do not lift or place supports on any part of the suspension system.

Brake Cleaning & Inspection

Your trailer brakes must be inspected and serviced at yearly intervals or more often as use and performance require. Magnets and shoes must be changed when they become worn or scored thereby preventing inadequate vehicle braking.

Clean the backing plate, magnet arm, magnet and brake shoes. Make certain that all the parts removed are replaced in the same brake and drum assembly. Inspect the magnet arm for any loose or worn parts. Check shoe return springs, hold down springs and adjuster springs for stretch or deformation and replace if required.



CAUTION: Asbestos Dust Hazard. Since some brake shoe friction materials contain asbestos, certain precautions need to be taken when servicing brakes:

1. Avoid creating or breathing dust.
2. Avoid machining, filing or grinding the brake linings.
3. Do not use compressed air or dry brushing for cleaning. (Dust can be removed with a damp brush).

TRAILER STORAGE

Preparation

If your trailer is to be stored for an extended period of time or over the winter, it is important that the trailer be prepared properly.

1. Remove the emergency breakaway battery and store inside, out of the weather. Charge the battery at least every 90 days.
2. Jack up the trailer and place jack stands under trailer frame so that the weight will be off the tires. Never jack up or place jack stands on the axle tube or on the equalizers.
3. Lubricate mechanical moving parts that are exposed to weather, such as the hitch and suspension parts.

Note: On oil lubricated hubs the upper part of the roller bearings are not immersed in oil and are subject to potential corrosion. For maximum bearing life it is recommended that you revolve your wheels periodically (every 2-3 weeks) during periods of prolonged storage.

After Prolonged Storage — Inspection Procedures


Before removing trailer from jack stands:

1. Remove all wheels and hubs or brake drums. Note which spindle and brake that the drum was removed from so that it can be reinstalled in the same location.
2. Inspect suspension for wear.
3. Check tightness of hanger bolt, shackle bolt and U-bolt nuts per recommended torque values.
4. Check brake linings, brake drums and armature faces for excessive wear or scoring.
5. Check brake magnets with an ohmmeter. The magnets should check 3.2 ohms. If shorted or worn excessively, replace.
6. Lubricate all brake moving parts using a high temperature brake lubricant. (LUBRIPLATE or equivalent).

CAUTION: Do not get grease or oil on brake linings or magnet face.

7. Remove any rust from braking surface and armature surface of drums with fine emery paper or crocus cloth. Protect bearings from contamination while so doing.
8. Inspect oil or grease seals for wear or nicks. Replace if necessary.
9. Lubricate hub bearings. Refer to procedure in manual.
10. Reinstall hubs and adjust bearing per instructions in manual.


TR-3500 EXPLODED VIEW



TR-3500 EXPLODED VIEW PARTS LIST

| ITEM | PART NO. | DESCRIPTION | QTY | ITEM | PART NO. | DESCRIPTION | QTY |
|------|-------------|--|------|------|-------------|--|----------|
| 1 | 8.912-404.0 | Frame, Assy (3500) | 1 | 28 | 9.802-261.0 | Hose, 3/4", Push-On | 12.5 ft |
| 2 | 8.912-405.0 | Fender, Single, Assy (2500, 3500) | 2 | 29 | 8.706-928.0 | Bushing, 1" x 1/2", Black Poly | 1 |
| 3 | 8.707-500.0 | Axle, 3500 lb. 64" Track (3500) | 1 | 30 | 9.802-131.0 | Elbow, 1/2" JIC x 1/2", 90° | 1 |
| | 8.707-499.0 | Axle, 3500 Lb., 60 Track, Elec. Brakes | 1 | 31 | 8.706-375.0 | Elbow, 1-1/2", FT x FT | 1 |
| | 8.730-458.0 | Axle, 3500 Lb., 60 Track, Hydraulic Brakes | 1 | 32 | 8.706-925.0 | Bushing, 3/4" x 1/2" Pipe | 1 |
| | 8.707-501.0 | Axle, 3500 Lb., 64 Track, Elec. Brakes | 1 | 33 | 8.706-829.0 | Elbow, 1/2" Street | 1 |
| | 8.707-502.0 | Axle, 3500 Lb., 64 Track, Hyd Brakes | 1 | 34 | 9.802-146.0 | Swivel, 1/2" MP x 3/4" GHF W/S | 1 |
| 4 | 8.707-488.0 | Springs, Leaf, 3500 lb. /Pr (3500) | 1 | 35 | 8.711-788.0 | Hose, Suction, Push-on | 12.66 ft |
| 5 | 8.725-529.0 | Wheel/Tire Assy., 15" Wheel | 2 | 36 | 8.706-917.0 | Bushing, 1/2" x 3/8", Brass | 1 |
| 6 | 8.707-497.0 | Chain, 5/16 Zinc Plated | 6 ft | 37 | 8.706-968.0 | Fitting, 3/4" Garden HS x 1/2" | 1 |
| | 8.718-661.0 | ▲ Bolt, 3/8" x 1-1/2", NC, HH, SS | 2 | 38 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2", 90° | 1 |
| | 8.718-988.0 | ▲ Washer, 7/16" Flat, SAE | 2 | 39 | 9.802-041.0 | Elbow, 3/8" Street, 45° | 1 |
| | 9.802-811.0 | ▲ Washer, 3/8" x 1-1/2", Fender | 4 | 40 | 9.802-147.0 | Swivel, 3/8" MP x 3/4", GHF W/S | 1 |
| | 8.719-024.0 | ▲ Washer, 3/8", SS, Lock | 2 | 41 | 9.802-767.0 | Screw, 3/8" x 3/4" HH NC, Whiz Loc | 12 |
| | 8.719-089.0 | ▲ Nut, 3/8" Hex, NC, SS | 2 | 42 | 9.802-781.0 | Nut, 3/8" Flange, Whiz Loc, NC | 12 |
| 7 | 8.707-498.0 | ▲ Hook "S" 5/16 Zinc | 2 | 43 | 9.802-206.0 | ▲ Clamp, Hose | 1 |
| 8 | 8.707-485.0 | Jack, Swivel w/Caster 1500 lb. | 1 | 44 | 9.802-794.0 | ▲ Nut, Cage, 1/4" x 12 GA | 8 |
| 9 | 8.707-512.0 | Lamp, Stop/Tail/Turn, Red | 2 | 45 | 8.912-401.0 | Signage, Plate | 1 |
| 10 | 8.707-513.0 | Lamp, License w/Holder | 1 | 46 | 8.706-992.0 | Adapter, 1/2" x 3/8" | 1 |
| 11 | 8.707-510.0 | ▲ Connector, 7 Prong | 1 | 48 | 8.912-403.0 | Bracket, Breakaway | 1 |
| | 8.707-511.0 | ▲ Plug, 7 Prong | 1 | 49 | 8.707-506.0 | Breakaway Kit w/Battery | 1 |
| 12 | 8.707-524.0 | Tank, 200 Gal, HDPE Const | 1 | 50 | 8.706-846.0 | Tee, 3/4" Female Pipe | 1 |
| | 8.707-523.0 | Tank, 100 Gal HDPE Const | 1 | 51 | 8.706-881.0 | Nipple, 3/4" Pipe x 1/2" Pipe | 1 |
| 13 | 8.707-526.0 | Strainer, 1" T Line | 1 | 52 | 9.802-064.0 | ▲ Grommet, Rubber, Nozzle Holder | 4 |
| 14 | 8.706-376.0 | Elbow, 1" PVC 80 | 1 | 53 | 8.900-522.0 | Label, CLP Warning, Do Not Stand or Step | 2 |
| 15 | 8.706-424.0 | Nipple, 1.5" Close PVC 80 | 2 | 54 | 9.802-052.0 | Bulkhead, 3/4" Poly Pro | 1 |
| 16 | 8.706-439.0 | Nipple, 1" Close PVC 80 | 2 | 55 | 8.706-117.0 | Nipple, 1" Black Pipe, Close | 2 |
| 17 | 8.706-484.0 | Bulkhead, 1" Poly Pro | 1 | 56 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2" 90 Dgr. | 1 |
| 18 | 8.706-490.0 | Bulkhead, 1-1/2" Poly Pro | 1 | 57 | 8.912-399.0 | Cover, Light Bracket | 2 |
| 19 | 8.706-512.0 | Float, Ball, Black Plastic | 1 | 58 | 8.912-398.0 | Bracket, Light Tail | 2 |
| 20 | 9.803-557.0 | Elbow, 3/4" x 3/4" 90 Dgr. | 4 | 59 | 8.706-207.0 | Elbow, 3/8" Street | 1 |
| 21 | 8.706-899.0 | Nipple, 3/4" JIC x 3/4" Pipe | 3 | 60 | 8.707-230.0 | Valve, 3 Way Brass 1" | 2 |
| 22 | 8.706-899.0 | Bushing 1" x 3/4" | 7 | 61 | 9.802-171.0 | Nipple, 3/8" x 3/8" Male | 2 |
| 23 | 9.802-152.0 | Swivel, 3/4" SAE Fem Push On | 10 | 62 | 8.707-233.0 | Valve, 1" Ball Brass | 1 |
| 24 | 8.707-025.0 | Stem, Float 10" | 1 | 63 | 8.749-879.0 | Adhesive, 10" Roll, 2.5" x 7" | 1 |
| 25 | 8.749-329.0 | Valve, 3/4" Plastic Float | 1 | 64 | | Vin Plate | 1 |
| 26 | 8.707-342.0 | Valve, 1-1/2" Ball, Polypuro | 1 | 65 | 9.807-347.0 | Label, Clear Lexan | 1 |
| 27 | 8.918-207.0 | Hose, 3/8 x 150", 2 Wire Swivel x Swivel | 1 | 66 | 9.802-730.0 | Bolt, 3/8" x 2-1/2" GR5 Zinc | 2 |
| | | | | 67 | 9.802-807.0 | Washer, 3/8", SAE, Flat Zinc | 4 |
| | | | | 68 | 9.802-779.0 | Nut, 3/8", ESNA, NC | 2 |
| | | | | | | ▲ Not Shown | |

TR-3500/PGHW EXPLODED VIEW



TR-3500/PGHW EXPLODED VIEW PARTS LIST


| ITEM | PART NO. | DESCRIPTION | QTY | ITEM | PART NO. | DESCRIPTION | QTY |
|------|-------------|---|------|------|-------------|---|---------|
| 1 | 8.912-404.0 | Frame, Assy (3500) | 1 | 28 | 9.802-261.0 | Hose, 3/4", Push-On | 12.5 ft |
| 2 | 8.912-405.0 | Fender, Single, Assy (2500, 3500) | 2 | 29 | 8.706-928.0 | Bushing, 1" x 1/2", Black Poly | 1 |
| 3 | 8.707-500.0 | Axle, 3500 lb. 64" Track (3500) | 1 | 30 | 9.802-131.0 | Elbow, 1/2" JIC x 1/2", 90° | 1 |
| | 8.707-499.0 | Axle, 3500 Lb., 60 Track, Elec. Brakes | 1 | 31 | 8.706-375.0 | Elbow, 1-1/2", FT x FT | 1 |
| | 8.730-458.0 | Axle, 3500 Lb., 60 Track, Hydraulic Brakes | 1 | 32 | 8.706-925.0 | Bushing, 3/4" x 1/2" Pipe | 1 |
| | 8.707-501.0 | Axle, 3500 Lb., 64 Track, Elec. Brakes | 1 | 33 | 8.706-829.0 | Elbow, 1/2" Street | 1 |
| | 8.707-502.0 | Axle, 3500 Lb., 64 Track, Hyd Brakes | 1 | 34 | 9.802-146.0 | Swivel, 1/2" MP x 3/4" GHF W/S | 1 |
| 4 | 8.707-488.0 | Springs, Leaf, 3500 lb. /Pr (3500) | 1 | 35 | 8.711-788.0 | Hose, Suction, Push-on | 11 ft |
| 5 | 8.725-529.0 | Wheel/Tire Assy., 15" Wheel | 2 | 36 | 8.706-917.0 | Bushing, 1/2" x 3/8", Brass | 1 |
| 6 | 8.707-497.0 | Chain, 5/16 Zinc Plated | 6 ft | 37 | 8.706-968.0 | Fitting, 3/4" Garden HS x 1/2" | 1 |
| | 8.718-661.0 | ▲ Bolt, 3/8" x 1-1/2", NC, HH, SS | 2 | 38 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2", 90° | 1 |
| | 8.718-988.0 | ▲ Washer, 7/16" Flat, SAE | 2 | 39 | 9.802-041.0 | Elbow, 3/8" Street, 45° | 1 |
| | 9.802-811.0 | ▲ Washer, 3/8" x 1-1/2", Fender | 4 | 40 | 9.802-147.0 | Swivel, 3/8" MP x 3/4", GHF W/S | 1 |
| | 8.719-024.0 | ▲ Washer, 3/8", SS, Lock | 2 | 41 | 9.802-767.0 | Screw, 3/8" x 3/4" HH NC, Whiz Loc | 12 |
| | 8.719-089.0 | ▲ Nut, 3/8" Hex, NC, SS | 2 | 42 | 9.802-781.0 | Nut, 3/8" Flange, Whiz Loc, NC | 12 |
| 7 | 8.707-498.0 | ▲ Hook "S" 5/16 Zinc | 2 | 43 | 9.802-206.0 | ▲ Clamp, Hose | 1 |
| 8 | 8.707-485.0 | Jack, Swivel w/Caster 1500 lb. | 1 | 44 | 9.802-794.0 | ▲ Nut, Cage, 1/4" x 12 GA | 8 |
| 9 | 8.707-512.0 | Lamp, Stop/Tail/Turn, Red | 2 | 45 | 8.912-401.0 | Signage, Plate | 1 |
| 10 | 8.707-513.0 | Lamp, License w/Holder | 1 | 46 | 8.706-992.0 | Adapter, 1/2" x 3/8" | 1 |
| 11 | 8.707-510.0 | ▲ Connector, 7 Prong | 1 | 48 | 8.912-403.0 | Bracket, Breakaway | 1 |
| | 8.707-511.0 | ▲ Plug, 7 Prong | 1 | 49 | 8.707-506.0 | Breakaway Kit w/Battery | 1 |
| 12 | 8.707-524.0 | Tank, 200 Gal, HDPE Const | 1 | 50 | 8.706-846.0 | Tee, 3/4" Female Pipe | 1 |
| | 8.707-523.0 | Tank, 100 Gal HDPE Const | 1 | 51 | 8.706-881.0 | Nipple, 3/4" Pipe x 1/2" Pipe | 1 |
| 13 | 8.707-526.0 | Strainer, 1" T Line | 1 | 52 | 9.802-064.0 | ▲ Grommet, Rubber, Nozzle Holder | 4 |
| 14 | 8.706-376.0 | Elbow, 1" PVC 80 | 1 | 53 | 8.900-522.0 | Label, CLP Warning, Do Not Stand or Step | 2 |
| 15 | 8.706-424.0 | Nipple, 1.5" Close PVC 80 | 2 | 54 | 9.802-052.0 | Bulkhead, 3/4" Poly Pro | 1 |
| 16 | 8.706-439.0 | Nipple, 1" Close PVC 80 | 2 | 55 | 8.706-117.0 | Nipple, 1" Black Pipe, Close | 1 |
| 17 | 8.706-484.0 | Bulkhead, 1" Poly Pro | 1 | 56 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2" 90 Dgr. | 1 |
| 18 | 8.706-490.0 | Bulkhead, 1-1/2" Poly Pro | 1 | 57 | 8.912-399.0 | Cover, Light Bracket | 2 |
| 19 | 8.706-512.0 | Float, Ball, Black Plastic | 1 | 58 | 8.912-398.0 | Bracket, Light Tail | 2 |
| 20 | 9.803-557.0 | Elbow, 3/4" x 3/4" 90 Dgr. | 4 | 59 | 8.706-207.0 | Elbow, 3/8" Street | 1 |
| 21 | 8.706-899.0 | Nipple, 3/4" JIC x 3/4" Pipe | 3 | 60 | 8.707-230.0 | Valve, 3 Way Brass 1" | 1 |
| 22 | 8.706-929.0 | Bushing 1" x 3/4" | 4 | 61 | 9.802-171.0 | Nipple, 3/8" x 3/8" Male | 2 |
| 23 | 9.802-152.0 | Swivel, 3/4" SAE Fem Push On | 8 | 62 | 8.706-833.0 | Elbow 1" Street Brass | 1 |
| 24 | 8.707-025.0 | Stem, Float 10" | 1 | 63 | 8.749-879.0 | Adhesive, 10" Roll, 2.5" x 7" | 1 |
| 25 | 8.749-329.0 | Valve, 3/4" Plastic Float | 1 | 64 | | Vin Plate | 1 |
| 26 | 8.707-342.0 | Valve, 1-1/2" Ball, Polypro | 1 | 65 | 9.807-349.0 | Label, Clear Lexan | 1 |
| 27 | 8.918-208.0 | Hose, 3/8 x 162", 2 Wire Swivel x Swivel | 1 | 66 | 9.802-730.0 | Bolt, 3/8" x 2-1/2" GR5 Zinc | 2 |
| | | | | 67 | 9.802-807.0 | Washer, 3/8", SAE, Flat Zinc | 4 |
| | | | | 68 | 9.802-779.0 | Nut, 3/8", ESNA, NC | 2 |

▲ Not Shown


TR-6000

Exploded View

Left Side



TR-6000 Exploded View Right Side



TR-6000**EXPLODED VIEW PARTS LIST**


| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-------------|--|--------|
| 1 | 8.706-376.0 | Elbow, 1" FIPT x FIPT, PVC 80 | 1 |
| 2 | 8.706-424.0 | Nipple, 1.5 x Close, PVC 80 | 1 |
| 3 | 8.706-439.0 | Nipple, 1", PVC 80, Close | 2 |
| 4 | 8.706-484.0 | Bulkhead, 1", Polypro, #60427 | 1 |
| 5 | 8.706-490.0 | Bulkhead, 1-1/2" Polypro #60124 | 1 |
| 6 | 8.706-512.0 | Ball, Float, Black Plastic | 1 |
| 7 | 9.803-557.0 | Elbow, 3/4" SAE x 3/4", 90 Deg. | 6 |
| 8 | 8.706-899.0 | Nipple, 3/4" JIC x 3/4" Pipe | 3 |
| 9 | 8.706-929.0 | Bushing, 1" x 3/4" Barstock | 7 |
| 10 | 9.802-152.0 | Swivel, 3/4" SAE Fem, Push-on | 10 |
| 11 | 8.707-025.0 | Stem, 10" Float | 1 |
| 12 | 8.749-329.0 | Valve, 3/4" Plastic Float | 1 |
| 13 | 8.707-342.0 | Valve, 1.5" Ball, FPT x FPT, Polypropylene | 1 |
| 15 | 8.707-485.0 | Jack, Swivel w/Caster, 1500 Lb. | 1 |
| 16 | 8.707-488.0 | Springs, Leaf, 3500 Lb. /Pr. | 2 |
| 17 | 8.725-529.0 | Wheel/Tire Assy, 15" Wheel, ST205/75D15 Tire | 4 |
| 18 | 8.707-497.0 | Chain, 5/16 Zinc Plated | 6 ft. |
| | 8.718-661.0 | ▲ Bolt, 3/8" x 1-1/2" NC, HH, SS | 2 |
| | 8.718-988.0 | ▲ Washer, 7/16", Flat, SAE | 2 |
| | 9.802-811.0 | ▲ Washer, 3/8" x 1-1/2" Fender | 4 |
| | 8.719-024.0 | ▲ Washer, 3/8", SS Lock | 2 |
| | 8.719-089.0 | ▲ Nut, 3/8", Hex, NC, SS | 2 |
| 19 | 8.707-498.0 | ▲ Hook, "S", 5/16" Zinc Plated | 2 |
| 20 | 8.707-503.0 | Axle, 3500 Lb. , 72" Track, Idler | 2 |
| | 8.707-504.0 | Axle, 3500B, 73" Track, Elec | 1 |
| | 8.707-505.0 | Axle, 3500B, 73" Track, Hyd | 2 |
| 21 | 8.707-512.0 | Lamp, Stop/Tail/Turn, Red, Flush Mnt | 2 |
| 22 | 8.707-510.0 | ▲ Connector, Socket, 7-Prong | 1 |
| | 8.707-511.0 | Plug, 7 Prong | 1 |
| 23 | 8.707-513.0 | Lamp, License w/Holder | 1 |
| 24 | 8.707-525.0 | Tank, 330 Gal. HDPE Constr. | 1 |
| 25 | 8.707-526.0 | Strainer, 1" T-Line, Trailers | 1 |
| 26 | 8.918-208.0 | Hose, 3/8" x 162", 2 Wire, Swivel x Swivel | 1 |
| 27 | 9.802-261.0 | Hose, 3/4" Push-On | 14 ft. |
| 28 | 8.706-928.0 | Bushing, 1" x 1/2" Black Poly | 1 |
| 29 | 9.802-131.0 | Elbow, 1/2" JIC x 1/2", 90° | 1 |

**TR-6000
EXPLODED VIEW PARTS LIST (CONT)**

| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-------------|--|-----------|
| 30 | 8.706-925.0 | Bushing, 3/4" x 1/2" Pipe | 1 |
| 31 | 8.706-829.0 | Elbow, 1/2" Street, Brass | 1 |
| 32 | 9.802-146.0 | Swivel, 1/2" MP x 3/4" GHF W/S | 1 |
| 33 | 8.711-788.0 | Hose, 3/4" Suction, Push-On | 13.66 ft. |
| 34 | 8.706-917.0 | Bushing, 1/2" x 3/8" Brass | 1 |
| 35 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2" MPT | 1 |
| 36 | 9.802-041.0 | Elbow, 3/8" STL, Street, 45° | 1 |
| 37 | 9.802-147.0 | Swivel, 3/8" MP x 3/4" GHF W/S | 1 |
| 38 | 9.802-206.0 | Clamp, Hose | 1 |
| 39 | 8.912-401.0 | Plate, Signage, Trailers | 1 |
| 40 | 9.802-767.0 | Screw, 3/8" x 3/4" HH NC, Whiz Loc | 12 |
| 41 | 9.802-781.0 | Nut, 3/8", Flange Whiz Loc, NC | 12 |
| 42 | 8.706-846.0 | Tee, 3/4" Female Pipe | 1 |
| 43 | 9.802-794.0 | Nut, Cage, 1/4" x 12 GA | 8 |
| 44 | 8.706-881.0 | Nipple, 3/4" Pipe x 1/2" Pipe | 1 |
| 45 | 8.912-396.0 | Assy, Tandem Fender, TR-6000 | 2 |
| 46 | 8.912-395.0 | Assy, Tandem Axle Frame, TR-6000 | 1 |
| 47 | 8.707-507.0 | Lamp, Side Marker, Red | 2 |
| 48 | 8.707-508.0 | Lamp, Side Marker, Amber | 2 |
| 49 | 8.707-509.0 | Lamp, Identification Bar | 1 |
| 50 | 8.912-403.0 | Bracket, Breakaway Trailer | 1 |
| 51 | 8.707-506.0 | Breakaway Kit w/Battery | 1 |
| 52 | 8.706-207.0 | Elbow, 3/8" Street | 1 |
| 53 | 8.707-233.0 | Valve, 1" Ball, Brass | 1 |
| 54 | 9.802-064.0 | Grommet, Rubber, Nozzle Holder | 7 |
| 55 | 8.706-968.0 | Fitting, 3/4" Garden HS x 1/2" | 1 |
| 56 | 8.900-522.0 | Label, CLP Warning, Do Not Stand or Step | 2 |
| 57 | 9.802-171.0 | Nipple, 3/8" x 3/8" | 2 |
| 58 | 8.707-489.0 | Hanger Kit, Tandem Axle | 1 |
| 59 | 8.912-398.0 | Bracket Tail Light | 2 |
| 60 | 8.912-399.0 | Cover, Light Bracket | 2 |
| 61 | 8.707-230.0 | Valve, 1" Brass | 2 |
| 62 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2", 90 Dgr | 1 |
| 63 | 8.706-117.0 | Nipple, 1" Close, Black | 2 |
| 64 | 9.802-052.0 | Bulkhead, 3/4" Polypro | 1 |
| 65 | 8.706-992.0 | Adapter, 1/2" x 3/8" | 1 |
| 66 | 8.749-879.0 | Adhesive, 10" Roll | 2.5" x 7" |
| 67 | | Vin Plate | 1 |
| 68 | 9.807-349.0 | Label, Clear Lexan | 1 |
| 69 | 9.802-730.0 | Bolt, 3/8" x 2-1/2" GR5 Zinc | 2 |
| 70 | 9.802-807.0 | Washer, 3/8", SAE, Flat Zinc | 4 |
| 71 | 9.802-779.0 | Nut, 3/8", ESNA, NC | 2 |


▲ Not Shown

TR-6000 PGHW EXPLODED VIEW LEFT SIDE



89139560-9

TR-6000 PGHW EXPLODED VIEW RIGHT SIDE




TR-6000 PGHW EXPLODED VIEW PARTS LIST

| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-------------|---|-----------|
| 1 | 8.706-376.0 | Elbow, 1" FIPT x FIPT, PVC 80 | 1 |
| 2 | 8.706-424.0 | Nipple, 1.5 x Close, PVC 80 | 1 |
| 3 | 8.706-439.0 | Nipple, 1", PVC 80, Close | 2 |
| 4 | 8.706-484.0 | Bulkhead, 1", Polypro, #60427 | 1 |
| 5 | 8.706-490.0 | Bulkhead, 1-1/2" Polypro #60124 | 1 |
| 6 | 8.706-512.0 | Ball, Float, Black Plastic | 1 |
| 7 | 9.803-557.0 | Elbow, 3/4" SAE x 3/4", 90 Deg. | 5 |
| 8 | 8.706-899.0 | Nipple, 3/4" JIC x 3/4" Pipe | 3 |
| 9 | 8.706-929.0 | Bushing, 1" x 3/4" Barstock | 5 |
| 10 | 9.802-152.0 | Swivel, 3/4" SAE Fem, Push-on | 8 |
| 11 | 8.707-025.0 | Stem, 10" Float | 1 |
| 12 | 8.749-329.0 | Valve, 3/4" Plastic Float | 1 |
| 13 | 8.707-342.0 | Valve, 1.5" Ball, FPT x FPT, Polypropylene | 1 |
| 14 | 8.706-992.0 | Adapter, 1/2" x 3/8" | 1 |
| 15 | 8.707-485.0 | Jack, Swivel w/Caster, 1500 Lb. | 1 |
| 16 | 8.707-488.0 | Springs, Leaf, 3500 Lb. /Pr. | 2 |
| 17 | 8.725-529.0 | Wheel/Tire Assy, 15" Wheel, ST205/75D15 Tire | 4 |
| 18 | 8.707-497.0 | Chain, 5/16 Zinc Plated | 6 ft. |
| | 8.718-661.0 | ▲ Bolt, 3/8" x 1-1/2" NC, HH, SS | 2 |
| | 8.718-988.0 | ▲ Washer, 7/16", Flat, SAE | 2 |
| | 9.802-811.0 | ▲ Washer, 3/8" x 1-1/2" Fender | 4 |
| | 8.719-024.0 | ▲ Washer, 3/8", SS Lock | 2 |
| | 90-500ST | ▲ Nut, 3/8", Hex, NC, SS | 2 |
| 19 | 8.707-498.0 | ▲ Hook, "S", 5/16" Zinc Plated | 2 |
| 20 | 8.707-503.0 | Axle, 3500 Lb. , 72" Track, Idler | 2 |
| | 8.707-504.0 | Axle, 3500B, 73" Track, Elec | 1 |
| | 8.707-505.0 | Axle, 3500B, 73" Track, Hyd | 2 |
| 21 | 8.707-512.0 | Lamp, Stop/Tail/Turn, Red, | 2 |
| 22 | 8.707-510.0 | ▲ Connector, Socket, 7-Prong | 1 |
| | 8.707-511.0 | Plug, 7 Prong | 1 |
| 23 | 8.707-513.0 | Lamp, License w/Holder | 1 |
| 24 | 8.707-525.0 | Tank, 330 Gal. HDPE Constr. | 1 |
| 25 | 8.707-526.0 | Strainer, 1" T-Line, Trailers | 1 |
| 26 | 8.918-208.0 | Hose, 3/8" x 162", 2 Wire, Swivel x Swivel | 1 |
| 27 | 9.802-261.0 | Hose, 3/4" Push-On | 14 ft. |
| 28 | 8.706-928.0 | Bushing, 1" x 1/2" Black Poly | 1 |
| 29 | 9.802-131.0 | Elbow, 1/2" JIC x 1/2", 90° | 1 |
| 30 | 8.706-925.0 | Bushing, 3/4" x 1/2" Pipe | 1 |
| 30 | 8.706-925.0 | Bushing, 3/4" x 1/2" Pipe | 1 |
| 31 | 8.706-829.0 | Elbow, 1/2" Street, Brass | 1 |
| 32 | 9.802-146.0 | Swivel, 1/2" MP x 3/4" GHF W/S1 | |
| 33 | 8.711-788.0 | Hose, 3/4" Push-On, | 13.66 ft. |

| ITEM | PART NO. | DESCRIPTION | QTY |
|------|-------------|---|-----|
| 34 | 8.706-917.0 | Bushing, 1/2" x 3/8" Brass | 1 |
| 35 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2" MPT | 1 |
| 36 | 9.802-041.0 | Elbow, 3/8" STL, Street, 45° | 1 |
| 37 | 9.802-147.0 | Swivel, 3/8" MP x 3/4" GHF W/S1 | |
| 38 | 9.802-206.0 | ▲ Clamp, Hose | 1 |
| 39 | 8.912-401.0 | Plate, Signage, Trailers | 1 |
| 40 | 9.802-767.0 | Screw, 3/8" x 3/4" Whiz Loc | 12 |
| 41 | 9.802-781.0 | Nut, 3/8", Flange Whiz Loc, NC | 12 |
| 42 | 8.706-846.0 | Tee, 3/4" Female Pipe | 1 |
| 43 | 9.802-794.0 | ▲ Nut, Cage, 1/4" x 12 GA | 8 |
| 44 | 8.706-881.0 | Nipple, 3/4" Pipe x 1/2" Pipe | 1 |
| 45 | 8.912-396.0 | Assy, Tandem Fender, TR-6000 | 2 |
| 46 | 8.912-395.0 | Assy, Tandem Axle Frame, TR-6000 | 1 |
| 47 | 8.707-507.0 | Lamp, Side Marker, Red | 2 |
| 48 | 8.707-508.0 | Lamp, Side Marker, Amber | 2 |
| 49 | 8.707-509.0 | Lamp, Identification Bar | 1 |
| 50 | 8.912-403.0 | ▲ Bracket, Breakaway Trailer | 1 |
| 51 | 8.707-506.0 | Breakaway Kit w/Battery | 1 |
| 52 | 8.706-207.0 | Elbow, 3/8" Street | 1 |
| 53 | 9.802-064.0 | ▲ Grommet, Rubber, Nozzle Holder | 7 |
| 54 | 8.706-968.0 | Fitting, 3/4" Garden HS x 1/2" | 1 |
| 55 | 8.900-522.0 | Label, CLP Warning, Do Not Stand or Step | 2 |
| 56 | 9.802-171.0 | Nipple, 3/8" x 3/8" | 2 |
| 57 | 8.707-489.0 | Hanger Kit, Tandem Axle | 1 |
| 58 | 8.912-398.0 | Bracket Tail Light | 2 |
| 59 | 8.912-399.0 | Cover, Light Bracket | 2 |
| 60 | 8.707-230.0 | Valve, 1" Brass | 1 |
| 61 | 9.802-132.0 | Elbow, 3/4" JIC x 1/2", 90° | 1 |
| 62 | 8.706-117.0 | Nipple, 1" Close, Black | 1 |
| 63 | 9.802-052.0 | Bulkhead, 3/4" Polypro | 1 |
| 64 | 8.706-833.0 | 1" Street Brass | 1 |
| 65 | 8.749-879.0 | Adhesive, 10" Roll, 2.5" x 7" | 1 |
| 66 | | Vin Plate | 1 |
| 67 | 9.807-349.0 | Label, Clear Lexan | 1 |
| 68 | 9.802-730.0 | Bolt, 3/8" x 2-1/2" GR5 Zinc | 2 |
| 69 | 9.802-807.0 | Washer, 3/8", SAE, Flat Zinc | 4 |
| 70 | 9.802-779.0 | Nut, 3/8", ESNA, NC | 2 |
| 71 | 9.802-167.0 | Coupler, 3/8" Socket, Female 11000 PSI (PGHW-50524E Only) | 1 |
| | 9.802-166.0 | Coupler, 3/8" Socket, Female Brass | 1 |

▲ Not Shown

WIRING DIAGRAM



PREVENTATIVE MAINTENANCE

This trailer was produced with the best available materials and quality craftsmanship. However, you as the owner, have certain responsibilities for the correct care of the equipment. Attention to regular preventative maintenance procedures will assist in preserving the performance of your equipment.

| MAINTENANCE SCHEDULE | | |
|---|--|---------------------------|
| Tire Air Pressure | Inflate to proper pressure indicated on sidewall | Every Trip |
| Wheel Lugs, Bolts & Nuts | Tighten to proper torque specifications | Every 3000 mi or 3 mos.* |
| Wheel | Check for damage and or out-of-round | Every 6000 mi or 6 mos. |
| Coupler Ball | Check for sufficient lube. Check lock mechanism. Check for unusual wear. | Every trip |
| Safety Chains at Hitch Ball | Check for abrasion, distortion and general integrity of links. | Every trip |
| Coupler | Check for proper fastening & hitch pin in position and secure. | Every trip |
| Brakes | Check for proper adjustment & operation | Every trip |
| Breakaway Switch | Test switch operation and connections | Every trip |
| Breakaway Battery | Pull switch pin, check charge indicator light | Every trip |
| Load Distribution | Check load distribution & security | Every trip |
| Leveling Jacks | Check fastenings. Lube. | Every trip |
| Welds | Check all weld beads for cracks or separations | Every 6000 mi. or 6 mos. |
| Hinges | Grease zerks with a Lithium complex grease | Every 3000 mi. or 3 mos. |
| Tie Down Devices | Check for fracturing, distortion and improper anchoring. | Every 3000 mi., or 3 mos. |
| Electrical: Lights & Signals | Check to make sure all are working properly. Replace burned out bulbs. | Every trip |
| * Check lug nuts for tightness before initial trip, at 10 miles, 25 miles and 50 miles. Recheck at least every 3 months or 3000 miles | | |


Axles, Hubs and Brakes

Your Landa trailer is equipped with Dexter Component Axles. The Dexter Owner's Manual is included in the materials received with your trailer. Maintenance for axles, hubs and brakes is extremely important for protecting the longevity of your trailer. It is extremely important for your personal safety and the protection of others. Follow the Dexter service recommendations exactly as described.

Please, never shortcut axle, hub and brake service and maintenance.

TRAILER OPTIONS & ACCESSORIES


| Part No. | Description | Fits These Models |
|----------|-------------|-------------------|
|----------|-------------|-------------------|



Electric Breakaway Brake Kit

Brakes


| | | |
|-------------|---------------------------------|-----------|
| 8.902-437.0 | Kit, Electric Brakes (one axle) | TR-6000 |
| 8.902-438.0 | Kit, Surge Brakes (one axle) | TR-6000 |
| 8.902-440.0 | Kit, Electric Brakes | TR-3500 |
| 8.902-441.0 | Kit, Surge Brakes | TR-3500 |
| 8.707-506.0 | Kit, Breakaway, Electric Brakes | All Model |



Hose Reel

Landa Hose Reel Kits (Hose NOT Included)

| | | |
|-------------|--|------------|
| 8.902-447.0 | Kit, For 100' of 3/8" High Pressure Hose | All Models |
| 8.902-448.0 | Kit, For 200' of 3/8" High Pressure Hose | All Models |
| 8.902-449.0 | Kit, For 100' of 3/4" Garden Hose | All Models |




Chemical Rack

Chemical Rack

| | | |
|-------------|-------------------------------|------------------|
| 8.912-409.0 | 2-5 Gal. Bucket Chemical Rack | TR-3500, TR-6000 |
|-------------|-------------------------------|------------------|

Mounting Kits

| | | |
|-------------|----------------------------|-------------------|
| 8.902-454.0 | Kit, Mount & Plumbing SEHW | SGHW, SDHW, PGHW, |
| 8.902-456.0 | Kit, Mount & Plumbing | PGDC, MHP |
| 25-1022 | Kit, Mount & Plumbing | MVP |



Fuel Tank & Tool Box

Fuel Tank & Tool Box


| | | |
|-------------|---|---------|
| 8.902-464.0 | Kit, Fuel & Tool, 45 Gal. Tank | TR-6000 |
| 8.902-465.0 | Kit, Fuel & Tool, 24 Gal Tank | TR-6000 |
| 8.707-521.0 | Kit, Fuel & Tool Box Only, 45 Gal. Tank | TR-6000 |
| 8.707-522.0 | Kit, Fuel & Tool Box, 24 Gal. Tank | TR-6000 |

Vinyl Skid Cover


| | | |
|--------|------------------|------------------|
| 2-9025 | Vinyl Skid Cover | SGHW, SDHW |
| 2-9026 | Vinyl Skid Cover | PGHW, PGDC, SEHW |
| 2-9029 | Vinyl Skid Cover | MVP |

TRAILER OPTIONS & ACCESSORIES

Continued



High Pressure Hose



Garden Hose

| Part No. | Description | Fits These Models |
|----------------------------|---|-------------------|
| High Pressure Hoses | | |
| 8.739-028.0 | 3/8" x 100', 1-Wire, Tuff-Skin | |
| 8.739-074.0 | 3/8" x 100', 2-Wire, Tuff-Skin | |
| 8.739-220.0 | 3/8" x 100', 2-Wire, Tuff-Flex, Blue | |
| Garden Hoses | | |
| 8.711-798.0 | 50' x 3/4" | |
| 8.711-799.0 | 75' x 3/4" | |
| 8.711-800.0 | 100' x 3/4" | |
| Chrome Wheel/Fender | | |
| 8.902-466.0 | Upgrade to Chrome Wheels (per pair) | All Models |
| 8.902-468.0 | Upgrade to Chrome Fender Assy. Tandem Axle (per pair) | TR-6000 |
| 8.902-467.0 | Upgrade to Chrome Fender Assy., Single Axle (per pair) | TR-3500 |
| 8.707-493.0 | Chrome Wheel with ST205/75R14/C Tire (each) | All Models |
| Signage | | |
| 8.902-469.0 | Signage Plate | All Models |



LANDA LIMITED TRAILER WARRANTY
(Effective April 1999)

We warrant to the original purchaser that each new part and accessory sold by Landa will be free from manufacturing defects in materials or workmanship in normal service for a period of one (1) year from date of purchase, provided it is installed properly and the equipment maintained in accordance with Landa's instructions and manuals.

Our obligation under this warranty is expressly limited. As to the replacement or repair, at our option, at Landa Inc., Camas, Washington 98607, or at a service facility designated by us, for such part or parts as inspection shall disclose to have been defective.

EXCLUSIONS:

This warranty does not apply to defects caused by casualty or unreasonable use, including faulty repairs by others and failure to provide reasonable and necessary maintenance.

THE FOLLOWING ITEMS ARE NOT COVERED BY THIS WARRANTY:

Suspension axles, torflex axles, hubs, drums, brakes, bearings and seals. These are subject to the warranties, if any of their manufacturers.

WE SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OF ANY KIND, including but not limited to labor costs or transportation charges in connection with the replacement or repair of defective parts.

ANY IMPLIED OR STATUTORY WARRANTIES, INCLUDING WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE EXPRESSLY LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. We make no other express warranty, nor is anyone authorized to make any in our behalf.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state.

TO OBTAIN WARRANTY SERVICE:

Purchaser must bring the trailer to an authorized Landa Dealership. For the dealership nearest you consult our web page: www.landa-inc.com.

LANDA[®]